



Healthcare-IOT [wk14]




HealthCare Data -ECG/HR- Project

Visualization of Healthcare Signals using
Arduino & Node.js

HCit, INJE University

1st semester, 2018

Email : chaos21c@gmail.com





My ID

오전

성명	ID
김민선	HS01
김영걸	HS02
김주란	HS03
김주현	HS04
김태민	HS05
여준하	HS06
이수민	HS07
정민지	HS08
정유현	HS09
정재은	HS10
주하영	HS11
한준영	HS12

오후

성명	ID
신영주	HS21
오가영	HS22
윤민수	HS23
윤진아	HS24
이진영	HS25
임상은	HS26
임재형	HS27
최민영	HS28
황유빈	HS29



주간계획서

주간계획서			
주차	수업방법	수업내용	과제물
1	강의/실습	수업 및 실습 안내 - 포터블 소프트웨어 설치	
2	강의/실습	Node.js I - Node.js 코드의 기본 구조 - 기초 Node 서버 및 클라이언트	실습확인
3	강의/실습	Node.js II - Node.js Express 서버	실습확인
4	강의/실습/발표	Arduino I - 아날로그 신호 회로 - LCD를 이용한 센서 신호 모니터링	실습확인
5	강의/실습	Arduino II - 단일 센서 회로와 Node.js 연결 - 다중 센서 회로와 Node.js 연결	실습확인
6	강의/실습	프로젝트1 - 생체 센서 회로와 Node.js 연결 - 생체 신호 소개	프로젝트1
7	강의/실습/발표	IOT 데이터 시각화 I (Plotly.js) - 데이터 및 시계열 차트 - 데이터 스트리밍	실습확인
8	시험	중간고사	
9	강의/실습	IOT 데이터 시각화 II (Plotly.js) - 다중 센서 데이터 시각화 - 다중 센서 데이터 스트리밍	실습확인
10	강의/실습/발표	프로젝트II - 생체 센서 데이터 시각화 - 생체 센서 데이터 스트리밍	프로젝트II
11	강의/실습	IOT 데이터 저장과 처리 - MongoDB 설치 및 Mongo shell - MongoDB와 Node.js 연결 및 데이터 저장	실습확인
12	강의/실습	프로젝트III - MongoDB에 IOT 데이터 저장 및 모니터링 - 생체 센서 데이터 저장 및 시각화	프로젝트III
13	강의/실습	IOT 데이터 마이닝 - 아두이노에서 발생된 데이터 관리 - 데이터마이닝 소개	실습확인
14	강의/실습/발표	프로젝트IV - 생체 센서 데이터 관리 - 생체 센서 데이터 마이닝	프로젝트IV
15	시험	기말고사	




Purpose of HS


주요 수업 목표는 다음과 같다.

1. Node.js를 이용한 아두이노 센서 신호 처리
2. Plotly.js를 이용한 아두이노 센서 신호 시각화
3. MongoDB에 아두이노 센서 데이터 저장 및 처리
4. 생체 센서 발생 신호 처리, 시각화 및 저장
5. 생체 센서 발생 신호 저장 및 분석
6. 생체 신호 장비 활용 능력






[Review]



◆ [wk13]

- RT Data management with MongoDB
- Multi-sensor circuits
- Complete your project
- Upload file name : HSnn_Rpt11.zip



◆ [Target of this week]

- Complete your works.
- Save your outcomes and compress them.

제출파일명 : **HSnn_Rpt11.zip**

- 압축할 파일들



- ① **HSnn_iot_mongodb.png**
- ② **HSnn_iot_mongodb_web.png**
- ③ **HSnn_iot_json.png**
- ④ **HSnn_iot_DB.png**
- ⑤ **HSnn.csv (mongoexport file)**

Email : chaos21c@gmail.com

【 제목 : **id**, 이름 (수정) 】



[My working folder – wk14]







Arduino




+ Node.js



+ plotly.js

+ MongoDB






IOT: HSC




Layout [H S C]



Arduino data + plotly


Time series by HS00



Real-time Weather Station from sensors




on Time: 2018-01-22 17:58:31.012



MongoDB database visualization by HS00

Time series : Multi sensor data




Data visualization by HS00

Time series : ECG & PPG



Data visualization by Biochaos

Time series : HR & PR




HR: Web client → Real-time streaming

Real-time Heart rate(HR) from ECG sensor



on Time: 2018-06-06 17:39:50.228



A5. Introduction to visualization

System (Arduino, sDevice, ...)



Data (signal, image, sns, ...)




Visualization & monitoring




Data storing & mining



Service






[Goal of project]
Arduino + Node.js

+ plotly.js


+ MongoDB

→ Data storing
& visualization



**ECG
sensor
Module
SEN0213**

Arduino circuit





ECG & HR: sensor module – SEN0213

Heart Rate Monitor Sensor SKU: SEN0213





<https://www.dfrobot.com/product-1510.html>



ECG & HR: circuit




Connection Diagram




[https://www.dfrobot.com/wiki/index.php/Heart Rate Monitor Sensor SKU: SEN0213](https://www.dfrobot.com/wiki/index.php/Heart_Rate_Monitor_Sensor_SKU:_SEN0213)



ECG: standard wave form – lead I, II, III







Normal ECG





ECG: wave form






ECG: Arduino code - 1


```
11 const int heartPin = A1;  
12  
13 void setup() {  
14   Serial.begin(19200); // 9600, 115200  
15 }  
16  
17 void loop() {  
18   int heartValue = analogRead(heartPin);  
19   Serial.println(heartValue);  
20   delay(10); // fs = 100 Hz (sampling period = 10 sec)  
21 }
```

delay(10) → fs = 100 Hz





ECG: Arduino code - 1




작은 파형들은 전기적 잡음이며

전선이 흔들리면 서서히 변하는 잡음이 발생.



HR: Arduino code - 2

```
hcnn_ecg_HR$  
14 #include "HeartSpeed.h"  
15  
16 HeartSpeed heartspeed(A1); //The serial port for observing pulse.  
17 //HeartSpeed heartspeed(A1,RAW_DATA); //The serial port observation of ECG wave.  
18  
19 /* Print the position result */  
20 void mycb(uint8_t rawData, int value) // call-back function  
21 {  
22     if(rawData){  
23         Serial.println(value);  
24     }else{  
25         Serial.print("HeartRate Value = ");  
26         Serial.print(value);  
27         Serial.println(" (bpm)");  
28     }  
29 }  
30 void setup() {  
31     Serial.begin(115200);  
32     heartspeed.setCB(mycb); //Callback function.  
33     heartspeed.begin(); //The pulse test.  
34 }  
35  
36 void loop() {  
37 }  
38 }
```



HR

```
COM9 (Arduino Uno)  
heartRate value = 70  
HeartRate Value = 69  
HeartRate Value = 71  
HeartRate Value = 72  
HeartRate Value = 74  
HeartRate Value = 75  
HeartRate Value = 75  
HeartRate Value = 75  
HeartRate Value = 74  
HeartRate Value = 71  
HeartRate Value = 62  
HeartRate Value = 71  
HeartRate Value = 68  
HeartRate Value = 68  
HeartRate Value = 78  
HeartRate Value = 74  
HeartRate Value = 77
```




Arduino

& Node.js

& MongoDB



**ECG
sensor
Module
SEN0213**





ECG: Node.js – package.json

```
package.json

1  {
2      "name": "ecg_hr",
3      "version": "1.0.0",
4      "description": "ecg-hr-node project",
5      "main": "ecg_node.js",
6      "scripts": {
7          "test": "echo \\\"Error: no test specified\\\" && exit 1"
8      },
9      "author": "hs00",
10     "license": "MIT",
11     "dependencies": {
12         "cors": "^2.8.4",
13         "express": "^4.16.2",
14         "mongoose": "^5.0.1",
15         "serialport": "^4.0.7",
16         "socket.io": "^1.7.3"
17     }
18 }
```



ECG: Node.js – npm install

```
NodeJS
D:\Portable\NodeJSPortable\Data\hs00\ecg>dir
D 드라이브의 블루: DATA
블루 일련 번호: 7A01-106A

D:\Portable\NodeJSPortable\Data\hs00\ecg 디렉터리

2018-06-05 오전 11:13 <DIR> .
2018-06-05 오전 11:13 <DIR> ..
2018-06-05 오전 11:13 393 package.json
                      1개 파일 393 바이트
                      2개 디렉터리 867,170,316,288 바이트 남음

D:\Portable\NodeJSPortable\Data\hs00\ecg>npm install■
```

D:\Portable\NodeJSPortable\Data\hs00\ecg 디렉터리					
2018-06-05	오전 11:22	<DIR>	.	.	
2018-06-05	오전 11:22	<DIR>	.	.	
2018-06-05	오전 11:22	<DIR>		node_modules	
2018-06-05	오전 11:13		393	package.json	
		1개 파일		393	마이크로
		3개 디렉터리	867,142,000,640	바이트	남음



ECG: Arduino code – 1, new

```
11 const int heartPin = A1;  
12  
13 void setup() {  
14   Serial.begin(19200); // 9600, 115200  
15 }  
16  
17 void loop() {  
18   int heartValue = analogRead(heartPin);  
19   Serial.print("HSnnecg,");  
20   Serial.println(heartValue);  
21   delay(10); // fs = 100 Hz (sampling period = 10 sec)  
22 }
```



ECG: Arduino code – 1, new

The screenshot shows the Arduino Serial Monitor window. The port is set to COM7. The data window displays a series of messages: "HSnnecg,293", "HSnnecg,294", "HSnnecg,294", "HSnnecg,293", "HSnnecg,294", "HSnnecg,295", "HSnnecg,295", "HSnnecg,296", "HSnnecg,292", "HSnnecg,296", "HSnnecg,296", "HSnnecg,293", "HSnnecg,297", "HSnnecg,292", "HSnnecg,296", and "HSnnecg". A red dashed box highlights the first 15 lines of data. At the bottom, there are several configuration options: "자동 스크롤" (Auto Scroll) checked, "line ending 없음" (Line ending: None), a dropdown set to "19200 보드레이트" (Board Rate), and "출력 지우기" (Output Clear). The "19200 보드레이트" dropdown is also highlighted with a red dashed box.


직렬 통신 속도를 일치시켜야 신호 확인!



ECG: Arduino code – 1, new

COM7

↔ - □ ×



전기적 잡음이 과도함...



ECG: Node.js – `ecg_node_mongodb.js`

```
ecg_node_mongodb.js x
1 // ecg_node_mongodb.js
2
3 var serialport = require('serialport');
4 var portName = 'COM6'; // check your COM port!!
5 var port      = process.env.PORT || 3000;
6
7 var io = require('socket.io').listen(port);
8
9 // MongoDB
10 var mongoose = require('mongoose');
11 var Schema = mongoose.Schema;
12 // MongoDB connection
13 mongoose.connect('mongodb://localhost:27017/ecg'); // DB name
14     var db = mongoose.connection;
15     db.on('error', console.error.bind(console, 'connection error:'));
16     db.once('open', function callback () {
17         console.log("mongo db connection OK.");
18 });
19 // Schema
20 var iotSchema = new Schema({
21     date : String,
22     ecg  : String
23 });
24 // Display data on console in the case of saving data.
25 iotSchema.methods.info = function () {
26     var iotInfo = this.date
27     ? "Current date: " + this.date + ", ECG: " + this.ecg
28     : "I don't have a date"
29     console.log("iotInfo: " + iotInfo);
30 }
```



ECG: Node.js – `ecg_node_mongodb.js`

```
34 var sp = new serialport(portName,{  
35   baudRate: 9600,    // 9600  38400  
36   dataBits: 8,  
37   parity: 'none',  
38   stopBits: 1,  
39   flowControl: false,  
40   parser: serialport.parsers.readline('\r\n')  
41 });  
42 var readData = '';  
43 var ecgwave = '';  
44 var mdata = [];  
45 var firstcommaidx = 0;  
46 var Sensor = mongoose.model("Sensor", iotSchema);  
47 sp.on('data', function (data) {  
48   readData = data.toString();  
49   firstcommaidx = readData.indexOf(',');  
50   // parsing data into signals  
51   if (firstcommaidx > 0) {  
52     ecgwave = readData.substring(firstcommaidx + 1);  
53     readData = '';  
54     dStr = getDateString();  
55     mdata[0]=dStr; // Date  
56     mdata[1]=ecgwave; // ecg data  
57     var iot = new Sensor({date:dStr, ecg:ecgwave});  
58     // save iot data to MongoDB  
59     iot.save(function(err, iot) {  
60       if(err) return handleEvent(err);  
61       iot.info(); // Display the information of iot data on console.  
62     })  
63     io.sockets.emit('message', mdata); // send data to all clients  
64   } else { // error  
65     console.log(readData);  
66   }  
67 });
```



ECG: Node.js – `ecg_node_mongodb.js`

```
69 // helper function to get a nicely formatted date string for IOT
70 function getDateString() {
71     var time = new Date().getTime();
72     // 32400000 is (GMT+9 Korea, GimHae)
73     // for your timezone just multiply +/-GMT by 3600000
74     var datestr = new Date(time +32400000).
75     toISOString().replace(/T/, ' ').replace(/Z/, '');
76     return datestr;
77 }
78
79 io.sockets.on('connection', function (socket) {
80     // If socket.io receives message from the client browser then
81     // this call back will be executed.
82     socket.on('message', function (msg) {
83         console.log(msg);
84     });
85     // If a web browser disconnects from Socket.IO then this callback is called.
86     socket.on('disconnect', function () {
87         console.log('disconnected');
88     });
89 });
90
```




ECG: Node.js – `ecg_node_mongodb.js`

Run: `node ecg_node_mongodb.js` (Run in Node cmd)

```
COM7
HSnnecg,338
HSnnecg,245
HSnnecg,279
HSnnecg,325
HSnnecg,242
HSnnecg,337
HSnnecg,267
HSnnecg,241
HSnnecg,349
HSnnecg,263
HSnnecg,268
HSnnecg,322
HSnnecg,224
HSnnecg,358
HSnnecg,271
```



```
D:\Portable\NodeJSPortable\Data\hs00\ecg>node ecg_node_mongodb
mongo db connection OK.
iotInfo: Current date: 2018-06-05 12:37:32.257, ECG: 311
iotInfo: Current date: 2018-06-05 12:37:32.301, ECG: 308
iotInfo: Current date: 2018-06-05 12:37:32.303, ECG: 225
iotInfo: Current date: 2018-06-05 12:37:32.311, ECG: 323
iotInfo: Current date: 2018-06-05 12:37:32.311, ECG: 208
iotInfo: Current date: 2018-06-05 12:37:32.323, ECG: 226
iotInfo: Current date: 2018-06-05 12:37:32.355, ECG: 513
iotInfo: Current date: 2018-06-05 12:37:32.371, ECG: 454
iotInfo: Current date: 2018-06-05 12:37:32.387, ECG: 284
iotInfo: Current date: 2018-06-05 12:37:32.339, ECG: 506
```




```
명령 프롬프트 - mongo
> show dbs
aa00    0.000GB
admin   0.000GB
config  0.000GB
ecg     0.000GB
iot     0.000GB
iot2    0.000GB
iot3    0.001GB
local   0.000GB
test    0.000GB
test2   0.000GB
> -
```



[DIY]

Real-time WEB client to monitor ECG





ECG: Web client → client_ecg_gauge.html - 1

```
<!DOCTYPE html>
<head>
  <meta charset="utf-8">
  <title>plotly.js client: Real time signals from sensors</title>
  <script src="https://cdn.plot.ly/plotly-latest.min.js"></script>
  <script type="text/javascript" src="https://cdnjs.cloudflare.com/ajax/libs/socket.io/1.3.6/
  socket.io.js"></script>

  <script src="gauge.min.js"></script>

  <style>body{padding:0;margin:30;background:#fff}</style>
</head>

<body>  <!-- style="width:100%;height:100%"> -->
<!-- Plotly chart will be drawn inside this DIV -->
<h1 align="center">Real-time Electrocardiogram(ecg) from ECG sensor</h1>
<!-- Lux gauge -->
<div align="center">
  <canvas id="gauge"> </canvas>
</div>

<h3 align="center"> on Time: <span id="time"> </span> </h3>

<div id="myDiv"></div> <!-- graph here! -->

<hr>
```



ECG: Web client → client_ecg_gauge.html - 2

```
<script>
/* JAVASCRIPT CODE GOES HERE */
var streamPlot = document.getElementById('myDiv');
var ctime = document.getElementById('time');

var tArray = [], // time of data arrival
    xTrack = [], // value of ECG sensor 1
    numPts = 400, // number of data points
    dtda = [], // 1 x 2 array : [date, ecg]
    preX = -1, // check change in data
    initFlag = true;
```

```
var socket = io.connect('http://localhost:3000'); // port = 3000
socket.on('connect', function () {
  socket.on('message', function (msg) {
    // initial plot
    if(msg[0]!=='' && initFlag){
      dtda[0]=msg[0];
      dtda[1]=parseInt(msg[1]); // ecg
      init(); // start streaming
      initFlag=false;
    }
    console.log(msg[0]);
    console.log(parseInt(msg[1])); // Convert value to integer
    dtda[0]=msg[0];
    dtda[1] = parseInt(msg[1]);

    // when new data is coming, keep on streaming data
    ctime.innerHTML = dtda[0];
    gauge_ecg.setValue(dtda[1]); // ecg gauge
    //nextPt();
    tArray = tArray.concat(dtda[0]); // time
    tArray.splice(0,1);
    xTrack = xTrack.concat(dtda[1]); // ecg
    xTrack.splice(0,1);

    var update = {
      x: [tArray],
      y: [xTrack]
    }
    Plotly.update(streamPlot, update);
  });
});
```



ECG: Web client → client_ecg_gauge.html - 3

```
function init() { // initial screen ()  
  // starting point : first data (lux)  
  for ( i = 0; i < numPts; i++) {  
    tArray.push(dtda[0]); // date  
    xTrack.push(dtda[1]); // ecg  
  }  
  
  Plotly.plot(streamPlot, data, layout);  
}  
  
// data  
var data = [{  
  x : tArray,  
  y : xTrack,  
  name : 'ECG',  
  mode: "lines", //markers+lines  
  line: {  
    color: "#1f77b4",  
    width: 1  
  } //,  
  // marker: {  
  //   color: "rgb(255, 0, 0)",  
  //   size: 6,  
  //   line: {  
  //     color: "black",  
  //     width: 0.5  
  //   }  
  // }  
}];  
  
// layout  
var layout = {  
  xaxis : {  
    title : 'time',  
    domain : [0, 1]  
  },  
  yaxis : {  
    title : 'ECG',  
    domain : [0, 1],  
    range : [0, 500]  
  }  
};
```



ECG: Web client → client_ecg_gauge.html - 4

```
// gauge configuration
var gauge_ecg = new Gauge({
  renderTo : 'gauge',
  width : 300,
  height : 300,
  glow : true,
  units : 'AU',
  valueFormat : { int : 2, dec : 0 },
  title : "ECG",
  minValue : 0,
  maxValue : 500, // new
  majorTicks : ['0', '100', '200', '300', '400', '500'],
  minorTicks : 10,
  strokeTicks : false,
  highlights : [
    { from : 0, to : 100, color : '#aaa' },
    { from : 100, to : 200, color : '#ccc' },
    { from : 200, to : 300, color : '#ddd' },
    { from : 300, to : 400, color : '#eee' },
    { from : 400, to : 500, color : '#fff' }
  ],
  colors : {
    plate : '#df2578',
    majorTicks : '#f5f5f5',
    minorTicks : '#aaa',
    title : '#fff',
    units : '#ccc',
    numbers : '#eee',
    needle : { start : 'rgba(240, 128, 128, 1)', end : 'rgba(255, 160, 122, .9)' }
  }
});
gauge_ecg.draw();
```

ECG: Web client → Real-time streaming

Real-time Electrocardiogram(ecg) from ECG sensor



on Time: 2018-06-05 13:18:04.463





ECG: Node.js – `ecg_express.js`

```
1 // Express with CORS
2 var express = require('express');
3 var cors = require('cors'); // CORS: Cross Origin Resource Sharing
4 var app = express();
5 // CORS
6 app.use(cors());
7 var web_port = 3030; // express port
8
9 // MongoDB
10 var mongoose = require('mongoose');
11 var Schema = mongoose.Schema; // Schema object
12 // MongoDB connection
13 mongoose.connect('mongodb://localhost:27017/ecg'); // DB name
14 var db = mongoose.connection;
15 db.on('error', console.error.bind(console, 'connection error:'));
16 db.once('open', function callback () {
17     |     console.log("mongo db connection OK.");
18 });
19 // Schema
20 var iotSchema = new Schema({
21     date : String,
22     | ecg : String
23 });
24 var Sensor = mongoose.model("Sensor", iotSchema); // sensor data model
```




ECG: Node.js – `ecg_express.js`

```
27 // Web routing address
28 app.get('/', function (req, res) { // localhost:3030/
29   res.send('Hello Arduino-ECG IOT!');
30 });
31 // find all data & return them
32 app.get('/ecg', function (req, res) {
33   Sensor.find(function(err, data) {
34     res.json(data);
35   });
36 });
37 // find data by id
38 app.get('/ecg/:id', function (req, res) {
39   Sensor.findById(req.params.id, function(err, data) {
40     res.json(data);
41   });
42 });
43 // Express WEB
44 app.use(express.static(__dirname + '/public')); // WEB root folder
45 app.listen(web_port); // port 3030
46 console.log("Express_ECG_IOT is running at port:3030");
--
```



[DIY]

Real-time WEB client to monitor ECG from MongoDB





ECG: Web client → client_ecgDB.html - 1

```
<!DOCTYPE html>
<head>
    <meta charset="utf-8">
    <!-- Plotly.js -->
    <script src="https://cdn.plot.ly/plotly-latest.min.js"></script>
</head>
<body>
    <h1>MongoDB database visualization by HS00</h1>
    <hr>
    <h2>Time series : ECG data</h2>

    <!-- Plotly chart will be drawn inside this DIV -->
    <div id="myDiv" style="width: 1000px; height: 700px"></div>

    <script>
        <!-- JAVASCRIPT CODE GOES HERE -->
```



ECG: Web client → client_ecgDB.html - 2

```
Plotly.d3.json("http://localhost:3030/ecg", function(err, json){  
    //alert(JSON.stringify(json)); // It works!!!  
    //alert(JSON.parse(eval(json)));  
    if(err) throw err;  
  
    var date = [];  
    var ecg = [];  
    var jsonData = eval(JSON.stringify(json));  
  
    for (var i = 0; i < jsonData.length; i++) {  
        date[i] = jsonData[i].date;  
        ecg[i] = jsonData[i].ecg;  
    }  
  
    // time series of sensor data  
    var trace1 = {  
        type: "scatter",  
        mode: "lines",  
        name: 'Temperature',  
        x: date,  
        y: ecg,  
        line: {color: '#fc1234'}  
    }  
  
    var data = [trace1];
```



ECG: Web client → client_ecgDB.html - 3


```
// Layout with builtin rangeslider
var layout = {
  title: 'ecg with rangeslider',
  xaxis: {
    autorange: true,
    range: [date[0], date[date.length-1]],
    rangeslider: {buttons: [
      {
        count: 5,
        label: '5 s',
        step: 'second',
        stepmode: 'backward'
      },
      {
        count: 30,
        label: '30 s',
        step: 'second',
        stepmode: 'backward'
      }
    ]}}
```

```
{
  count: 1,
  label: '1 min',
  step: 'minute',
  stepmode: 'backward'
},
{
  count: 5,
  label: '5 min',
  step: 'minute',
  stepmode: 'backward'
},
{step: 'all'}
],
rangeslider: {range: [date[0], date[date.length-1]]},
type: 'date'
},
yaxis: {
  autorange: true,
  range: [0, 500],
  type: 'linear'
}
};

Plotly.newPlot('myDiv', data, layout);
```

MongoDB database visualization by HS00

Time series : ECG data




MongoDB database visualization by HS00

Time series : ECG data


Save as
HSnn_ecg_web.png

ecg with rangeslider



Save your ECG from MongoDB ‘ecg’


**Filename :
HSnn_ecg.csv**



HR
sensor
Module
SEN0213

Arduino

& Node.js & MongoDB





HR: Node.js – hr_node_mongodb.js – 1

```
hr_node_mongodbjs x
// hr_node_mongodb.js

var serialport = require('serialport');
var portName = 'COM7'; // check your COM port!!
var port      = process.env.PORT || 3000;

var io = require('socket.io').listen(port);

// MongoDB
var mongoose = require('mongoose');
var Schema = mongoose.Schema;
// MongoDB connection
mongoose.connect('mongodb://localhost:27017/hrv'); // DB name
  var db = mongoose.connection;
  db.on('error', console.error.bind(console, 'connection error:'));
  db.once('open', function callback () {
    console.log("mongo db connection OK.");
  });
// Schema
var hrSchema = new Schema({
  date : String,
  hr : String
});
// Display data on console in the case of saving data.
hrSchema.methods.info = function () {
  var hrInfo = this.date
  ? "Current date: " + this.date + ", HR: " + this.hr
  : "I don't have a date"
  console.log("hrInfo: " + hrInfo);
}
```



HR: Node.js – hr_node_mongodb.js – 2

```
// serial port object
var sp = new serialport(portName,{  
  baudRate: 115200, // 9600 19200 38400  
  dataBits: 8,  
  parity: 'none',  
  stopBits: 1,  
  flowControl: false,  
  parser: serialport.parsers.readline('\r\n')  
});  
  
var readData = ''; // this stores the buffer  
var hrv='';  
var mdata =[]; // this array stores date and data  
var firstcommaidx = 0;  
var Sensor = mongoose.model("Sensor", [hrSchema]);
```

```
sp.on('data', function (data) { // call back when data is received  
  readData = data.toString(); // append data to buffer  
  firstcommaidx = readData.indexOf(',')  
  // parsing data into signals  
  if (firstcommaidx > 0) {  
    hrv = readData.substring(firstcommaidx + 1);  
    readData = '';  
    dStr = getDateString();  
    mdata[0]=dStr; // Date  
    mdata[1]=hrv; // hr data  
    var iot = new Sensor({date:dStr, [hr:hrv]});  
    // save iot data to MongoDB  
    iot.save(function(err, iot) {  
      if(err) return handleEvent(err);  
      iot.info(); // Display the information  
    })  
    io.sockets.emit('message', mdata); // send data to clients  
  } else { // error  
    console.log(readData);  
  }  
});
```



HR: Node.js – hr_node_mongodb.js – 3

```
// helper function to get a nicely formatted date string
function getDateString() {
    var time = new Date().getTime();
    // 32400000 is (GMT+9 Korea, GimHae)
    // for your timezone just multiply +/-GMT by 3600000
    var datestr = new Date(time +32400000).
        toISOString().replace(/\T/, ' ').replace(/\Z/, '');
    return datestr;
}

io.sockets.on('connection', function (socket) {
    // If socket.io receives message from the client bro
    // this call back will be executed.
    socket.on('message', function (msg) {
        console.log(msg);
    });
    // If a web browser disconnects from Socket.IO then
    socket.on('disconnect', function () {
        console.log('disconnected');
    });
});
```



HR: Node.js – hr_node_mongodb.js

Run: node hr_node_mongodb.js (Run in Node cmd)

NodeJS - node hr_node_mongodb


```
D:\Portable\NodeJSPortable\Data\hs00\ecg>node hr_node_mongodb
mongo db connection OK.
hrInfo: Current date: 2018-06-05 15:10:52.937, HR: 141
hrInfo: Current date: 2018-06-05 15:10:53.944, HR: 141
hrInfo: Current date: 2018-06-05 15:10:54.985, HR: 141
hrInfo: Current date: 2018-06-05 15:10:56.090, HR: 141
hrInfo: Current date: 2018-06-05 15:10:57.195, HR: 109
hrInfo: Current date: 2018-06-05 15:10:58.332, HR: 89
hrInfo: Current date: 2018-06-05 15:10:59.435, HR: 92
hrInfo: Current date: 2018-06-05 15:11:01.726, HR: 94
hrInfo: Current date: 2018-06-05 15:11:02.829, HR: 95
hrInfo: Current date: 2018-06-05 15:11:03.950, HR: 98
hrInfo: Current date: 2018-06-05 15:11:05.056, HR: 85
hrInfo: Current date: 2018-06-05 15:11:07.297, HR: 79
hrInfo: Current date: 2018-06-05 15:11:08.385, HR: 86
hrInfo: Current date: 2018-06-05 15:11:18.889, HR: 80
hrInfo: Current date: 2018-06-05 15:11:20.008, HR: 80
```

```
명령 프롬프트 - mongo
> show dbs
aa00    0.000GB
admin   0.000GB
config  0.000GB
ecg     0.004GB
hrv     0.000GB
iot     0.000GB
iot2    0.000GB
iot3    0.001GB
local   0.000GB
test    0.000GB
test2   0.000GB
> -
```



[DIY]

Real-time WEB client to monitor **HR**




HR: Web client → Real-time streaming

Real-time Heart rate(HR) from ECG sensor



on Time: 2018-06-06 17:40:46.354





HR: Web client → client_hr_gauge.html - 1

```
<!DOCTYPE html>
<head>
  <meta charset="utf-8">
  <title>plotly.js client: Real time signals from sensors</title>
  <script src="https://cdn.plot.ly/plotly-latest.min.js"></script>
  <script type="text/javascript" src="https://cdnjs.cloudflare.com/ajax/libs/socket.io/1.3.6/
  socket.io.js"></script>

  <script src="gauge.min.js"></script>

  <style>body{padding:0;margin:30;background:#fff}</style>
</head>

<body>  <!-- style="width:100%;height:100%" -->
<!-- Plotly chart will be drawn inside this DIV -->
<h1 align="center">Real-time Heart rate(HR) from ECG sensor</h1>
<!-- Lux gauge -->
<div align="center">
  <canvas id="gauge"> </canvas>
</div>

<h3 align="center"> on Time: <span id="time"> </span> </h3>

<div id="myDiv"></div> <!-- graph here! -->

<hr>
```



HR: Web client → client_hr_gauge.html - 2

```
<script>
/* JAVASCRIPT CODE GOES HERE */
var streamPlot = document.getElementById('myDiv');
var ctime = document.getElementById('time');

var tArray = [], // time of data arrival
    xTrack = [], // value of HR
    numPts = 50, // number of data points
    dtda = [], // 1 x 2 array : [date, hr] from ECG
    preX = -1, // check change in data
    initFlag = true;
```

```
var socket = io.connect('http://localhost:3000');
socket.on('connect', function () {
  socket.on('message', function (msg) {
    // initial plot
    if(msg[0]!='' && initFlag){
      dtda[0]=msg[0];
      dtda[1]=parseInt(msg[1]); // hr
      init(); // start streaming
      initFlag=false;
    }
    console.log(msg[0]);
    console.log(parseInt(msg[1])); // Convert
    dtda[0]=msg[0];
    dtda[1] = parseInt(msg[1]);

    // when new data is coming, keep on stream
    ctime.innerHTML = dtda[0];
    gauge_hr.setValue(dtda[1]); // hr gauge
    //nextPt();
    tArray = tArray.concat(dtda[0]); // time
    tArray.splice(0,1);
    xTrack = xTrack.concat(dtda[1]); // hr
    xTrack.splice(0,1);

    var update = {
      x: [tArray],
      y: [xTrack]
    }
    Plotly.update(streamPlot, update);
  });
});
```



HR: Web client → client_hr_gauge.html - 3

```
function init() { // initial screen ()  
    // starting point : first data (lux)  
    for ( i = 0; i < numPts; i++) {  
        tArray.push(dtda[0]); // date  
        xTrack.push(dtda[1]); // hr  
    }  
  
    Plotly.plot(streamPlot, data, layout);  
}  
  
// data  
var data = [{  
    x : tArray,  
    y : xTrack,  
    name : "Heart rate",  
    mode: "lines", //markers+lines  
    line: {  
        color: "#1f77b4",  
        width: 1  
    },  
    // marker: {  
    //     color: "rgb(255, 0, 0)",  
    //     size: 6,  
    //     line: {  
    //         color: "black",  
    //         width: 0.5  
    //     }  
    // }  
}];
```

```
// layout  
var layout = {  
    xaxis : {  
        title : 'time',  
        domain : [0, 1]  
    },  
    yaxis : {  
        title : 'HR',  
        domain : [0, 1],  
        range : [0, 200]  
    }  
};
```



HR: Web client → client_hr_gauge.html - 4

```
// gauge configuration
var gauge_hr = new Gauge({
  renderTo    : 'gauge',
  width       : 300,
  height      : 300,
  glow        : true,
  units        : 'BPM',
  valueFormat : { int : 2, dec : 0 },
  title        : "HR",
  minValue     : 0,
  maxValue     : 200, // new
  majorTicks   : [ '0', '50', '100', '150', '200' ],
  minorTicks   : 10,
  strokeTicks  : false,
  highlights   : [
    { from : 0, to : 40, color : '#22f' },
    { from : 40, to : 60, color : '#77f' },
    { from : 60, to : 100, color : '#3f3' },
    { from : 100, to : 150, color : '#c77' },
    { from : 150, to : 200, color : '#f00' }
  ],
  colors       : {
    plate        : '#888888',
    majorTicks   : '#f5f5f5',
    minorTicks   : '#aaa',
    title        : '#fff',
    units        : '#ccc',
    numbers      : '#eee',
    needle       : { start : 'rgba(240, 128, 128, 1)', end : 'rgba(255, 160, 122, .9)' }
  }
});
gauge_hr.draw();
```




HR: Web client → Real-time streaming

Real-time Heart rate(HR) from ECG sensor



on Time: 2018-06-06 17:31:02.684




HR: Web client → Real-time streaming

Real-time Heart rate(HR) from ECG sensor



Save as
HSnn_hr.png

on Time: 2018-06-06 17:39:50.228





HR: Node.js – hr_express.js – 1

```
// hr_express.js
// Express with CORS
var express = require('express');
var cors = require('cors'); // CORS: Cross Origin Resource Sharing
var app = express();
// CORS
app.use(cors());
var web_port = 3030; // express port

// MongoDB
var mongoose = require('mongoose');
var Schema = mongoose.Schema; // Schema object
// MongoDB connection
mongoose.connect('mongodb://localhost:27017/hrv'); // DB name
var db = mongoose.connection;
db.on('error', console.error.bind(console, 'connection error:'));
db.once('open', function callback () {
    console.log("mongo db connection OK.");
});
```



HR: Node.js – hr_express.js – 2

```
// Schema
var hrSchema = new Schema({
  date : String,
  hr : String
});
var Sensor = mongoose.model("Sensor", hrSchema); // sensor data model

// Web routing address
app.get('/', function (req, res) { // localhost:3030/
  res.send('Hello Arduino-HR IOT!');
});

// find all data & return them
app.get('/hrv', function (req, res) {
  Sensor.find(function(err, data) {
    res.json(data);
  });
});


// find data by id
app.get('/hrv/:id', function (req, res) {
  Sensor.findById(req.params.id, function(err, data) {
    res.json(data);
  });
});

// Express WEB
app.use(express.static(__dirname + '/public')); // WEB root folder
app.listen(web_port); // port 3030
console.log("Express_HR_IOT is running at port:3030");
```




[DIY]

Real-time WEB client to monitor **HR** **from MongoDB**



MongoDB database visualization by HS00

Time series : HR data





HR: Web client → client_hrDB.html - 1

```
<!DOCTYPE html>
<head>
  <meta charset="utf-8">
  <!-- Plotly.js -->
  <script src="https://cdn.plot.ly/plotly-latest.min.js"></script>
</head>
<body>
  <h1>MongoDB database visualization by HS00</h1>
  <hr>
  <h2>Time series : HR data</h2>

  <!-- Plotly chart will be drawn inside this DIV -->
  <div id="myDiv" style="width: 1000px; height: 700px"></div>

  <script>
    <!-- JAVASCRIPT CODE GOES HERE -->
```



HR: Web client → client_hrDB.html - 2

```
Plotly.d3.json("http://localhost:3030/hrv", function(err, json){  
    //alert(JSON.stringify(json)); // It works!!!  
    //alert(JSON.parse(eval(json)));  
    if(err) throw err;  
  
    var date = [];  
    var hrv = [];  
    var jsonData = eval(JSON.stringify(json));  
  
    for (var i = 0; i < jsonData.length; i++) {  
        date[i] = jsonData[i].date;  
        hrv[i] = jsonData[i].hr;  
    }  
    // time series of sensor data  
    var trace1 = {  
        type: "scatter",  
        mode: "lines+markers",  
        name: 'Heart rate',  
        x: date,  
        y: hrv,  
        line: {color: '#fc1234'}  
    }  
  
    var data = [trace1];
```



HR: Web client → client_hrDB.html - 3


```
// Layout with builtin rangeslider
var layout = {
  title: 'HR with rangeslider',
  xaxis: {
    autorange: true,
    range: [date[0], date[date.length-1]],
    rangeselector: {buttons: [
      {
        count: 5,
        label: '5 s',
        step: 'second',
        stepmode: 'backward'
      },
      {
        count: 30,
        label: '30 s',
        step: 'second',
        stepmode: 'backward'
      }
    ],
    },
    type: 'date'
  }
};
```

```
{
  count: 1,
  label: '1 min',
  step: 'minute',
  stepmode: 'backward'
},
{
  count: 5,
  label: '5 min',
  step: 'minute',
  stepmode: 'backward'
},
{step: 'all'}
],
rangeslider: {range: [date[0], date[date.length-1]]},
type: 'date'
},
yaxis: {
  autorange: true,
  range: [0, 200],
  type: 'linear'
}
};

Plotly.newPlot('myDiv', data, layout);
})
```

MongoDB database visualization by HS00

Time series : HR data






HR data in MongoDB

NodeJS - node hr_node_mongodb

```
hrInfo: Current date: 2018-06-05 15:23:46.916, HR: 89
hrInfo: Current date: 2018-06-05 15:23:48.006, HR: 82
hrInfo: Current date: 2018-06-05 15:23:49.095, HR: 81
hrInfo: Current date: 2018-06-05 15:23:50.200, HR: 76
hrInfo: Current date: 2018-06-05 15:23:51.288, HR: 80
hrInfo: Current date: 2018-06-05 15:23:52.394, HR: 77
hrInfo: Current date: 2018-06-05 15:23:53.483, HR: 75
hrInfo: Current date: 2018-06-05 15:23:54.588, HR: 75
hrInfo: Current date: 2018-06-05 15:23:55.691, HR: 76
hrInfo: Current date: 2018-06-05 15:23:56.780, HR: 78
hrInfo: Current date: 2018-06-05 15:23:57.886, HR: 76
hrInfo: Current date: 2018-06-05 15:23:58.973, HR: 78
hrInfo: Current date: 2018-06-05 15:24:00.079, HR: 77
hrInfo: Current date: 2018-06-05 15:24:01.168, HR: 75
hrInfo: Current date: 2018-06-05 15:24:02.273, HR: 73
hrInfo: Current date: 2018-06-05 15:24:03.377, HR: 75
hrInfo: Current date: 2018-06-05 15:24:04.465, HR: 75
hrInfo: Current date: 2018-06-05 15:24:05.569, HR: 74
hrInfo: Current date: 2018-06-05 15:24:06.674, HR: 76
hrInfo: Current date: 2018-06-05 15:24:07.779, HR: 75
hrInfo: Current date: 2018-06-05 15:24:08.867, HR: 73
hrInfo: Current date: 2018-06-05 15:24:09.972, HR: 72
hrInfo: Current date: 2018-06-05 15:24:11.077, HR: 73
hrInfo: Current date: 2018-06-05 15:24:12.182, HR: 72
hrInfo: Current date: 2018-06-05 15:24:13.272, HR: 76
hrInfo: Current date: 2018-06-05 15:24:14.374, HR: 76
hrInfo: Current date: 2018-06-05 15:24:15.479, HR: 81
hrInfo: Current date: 2018-06-05 15:24:16.570, HR: 87
hrInfo: Current date: 2018-06-05 15:24:17.657, HR: 81
hrInfo: Current date: 2018-06-05 15:24:18.747, HR: 74
hrInfo: Current date: 2018-06-05 15:24:19.852, HR: 71
hrInfo: Current date: 2018-06-05 15:24:20.956, HR: 74
hrInfo: Current date: 2018-06-05 15:24:22.060, HR: 75
hrInfo: Current date: 2018-06-05 15:24:23.148, HR: 78
hrInfo: Current date: 2018-06-05 15:24:24.254, HR: 78
hrInfo: Current date: 2018-06-05 15:24:25.342, HR: 80
hrInfo: Current date: 2018-06-05 15:24:26.446, HR: 78
hrInfo: Current date: 2018-06-05 15:24:27.536, HR: 77
hrInfo: Current date: 2018-06-05 15:24:28.639, HR: 80
```



명령 프롬프트 - mongo

```
> db.sensors.find().pretty().limit(7)
{
    "_id" : ObjectId("5b16296cb3dea26bb80a926c"),
    "date" : "2018-06-05 15:10:52.937",
    "hr" : "141",
    "__v" : 0
}
{
    "_id" : ObjectId("5b16296db3dea26bb80a926d"),
    "date" : "2018-06-05 15:10:53.944",
    "hr" : "141",
    "__v" : 0
}
{
    "_id" : ObjectId("5b16296eb3dea26bb80a926e"),
    "date" : "2018-06-05 15:10:54.985",
    "hr" : "141",
    "__v" : 0
}
{
    "_id" : ObjectId("5b162970b3dea26bb80a926f"),
    "date" : "2018-06-05 15:10:56.090",
    "hr" : "141",
    "__v" : 0
}
{
    "_id" : ObjectId("5b162971b3dea26bb80a9270"),
    "date" : "2018-06-05 15:10:57.195",
    "hr" : "109",
    "__v" : 0
}
{
    "_id" : ObjectId("5b162972b3dea26bb80a9271"),
    "date" : "2018-06-05 15:10:58.332",
    "hr" : "89",
    "__v" : 0
}
{
    "_id" : ObjectId("5b162973b3dea26bb80a9272"),
    "date" : "2018-06-05 15:10:59.435",
    "hr" : "92",
    "__v" : 0
}
```

**Save your HR
from MongoDB ‘hrv’**

**Filename :
HSnn_hr.csv**

MongoDB data management

- Query in mongo shell
- Export & import MongoDB
- Using and understanding iot data with Python or R



A5.9.8 MongoDB management

2.2 Export MongoDB (windows cmd 창에서 실행, dbName을 iot로 변경!)

➤ mongoexport -d s_all -c sensors --type=csv --fields date,temperature,humidity,luminosity --limit=100 --out s100.csv

```
명령 프롬프트
D:\mongodb>mongoexport -d s_all -c sensors --type=csv --fields date,temperature,humidity,luminosity
--limit=100 --out s100.csv
2018-05-27T22:38:05.300+0900 connected to: localhost
2018-05-27T22:38:05.405+0900 exported 100 records

D:\mongodb>dir
D 드라이브의 볼륨: Yi_Data
볼륨 일련 번호: 3A94-C8A0

D:\mongodb 디렉터리

2018-05-27 오후 10:38 <DIR> .
2018-05-27 오후 10:38 <DIR> ..
2018-05-27 오후 10:26 <DIR> data
2018-05-26 오후 12:55 26,267 mongodb_export.PNG
2018-05-27 오후 05:58 193,912 mongodb_export_csv.png
2018-05-27 오후 05:20 177,001 mongo_export_count.png
2018-04-06 오후 09:37 83,233 R_Im_notebook.png
2018-05-27 오후 10:38 3,459 s100.csv
2018-05-26 오후 12:52 397 sensor10.csv
2018-05-26 오후 12:54 8,251,185 sensor_all.csv
7개 파일 8,735,454 바이트
3개 디렉터리 812,751,392,768 바이트 남음

D:\mongodb>
```



A5.9.8 MongoDB management

2.3 Advanced export with query (windows cmd 창에서 실행)

iot11 db의 특정 시간 이후의 데이터 100개를 csv 파일 (s100.csv)로 저장

➤ mongoexport -d iot11 -c sensors /query:"{date: {\$gt: '2018-05-29 22:26:05'}}"
--limit=100 --fields date,temperature,humidity,luminosity --type=csv
--out s100.csv


```
C:\#Users#\biochaos>mongoexport -d iot11 -c sensors /query:"{date: {$gt: '2018-05-29 22:26:05'}}" --limit 100 --fields date,temperature,humidity,luminosity --type=csv --out sensor100.csv
2018-05-29T22:49:19.431+0900      connected to: localhost
2018-05-29T22:49:19.576+0900      exported 100 records
```

[Tip] iot db의 최근 데이터 500개를 csv 파일 (s500.csv)로 저장할 때,

➤ mongoexport -d iot -c sensors --sort “{_id: -1}” --limit=500 --fields date,temperature,humidity,luminosity --type=csv --out s500.csv




[Practice]



◆ [wk14]

- ECG Data management with MongoDB
- ECG-HR monitoring
- Complete your project
- Upload file name : HSnn_Prj2.zip



[wk14] Project-2 HSnn_Prj2.zip



◆ [Target of this week]

- Complete your works.
- Save your data and compress them.

제출파일명 : **HSnn_Prj2.zip**

- 압축할 파일들

- ① **HSnn_ecg_web.png**
- ② **HSnn_ecg.csv**
- ③ **HSnn_hr.png**
- ④ **HSnn_hr.csv**

Email : chaos21c@gmail.com

【 제목 : **id**, 이름 (수정) 】

기말고사

Arduino & Node & MongoDB

[1] 과목명 : 헬스케어신호처리개론 (헬스케어IT 학과 2학년)

[2] 6월 14일(목), 5교시: 오후 1시~2시 (장소 : F1002)

[3] 필기 시험 (20점)

- Arduino, NodeJS, MongoDB Coding에서 20문제
(선다형/단답형/서술형)

- 수업 시간에 배운 Code의 이해와 활용 능력 평가

- github > src > core_code_final 폴더를 참조
(cds_dht222, ecg_hr, MongoDB)


**** 잘 준비해서 웃기를 ... ^_^

Lecture materials




● References & good sites

- ✓ <http://www.nodejs.org/ko> Node.js
- ✓ <http://www.arduino.cc> Arduino Homepage
- ✓ <http://www.w3schools.com> By w3schools
- ✓ <http://www.github.com> GitHub
- ✓ <http://www.google.com> Googling



A screenshot of a GitHub user profile page. At the top, there's a navigation bar with icons for back, forward, and search, followed by the URL "GitHub, Inc. [US] | https://github.com Redwoods (Redwoods Yi) - GitHub". To the right are icons for search, refresh, notifications, and account management. Below the bar, the GitHub logo is on the left, followed by links for "Features", "Business", "Explore", "Marketplace", and "Pricing". A search bar says "Search GitHub". On the far right, there are "Sign in or Sign up" buttons.



Redwoods Yi

Redwoods

[Block or report user](#)

 GimHae, Republic of Korea

Overview

Repositories 5

Stars 2

Followers 0

Following 0

Pinned repositories

dht22-iot-project

Iot project to monitor data streaming from DHT22 wired at Arduino.

HTML

Lec

All lectures by Redwoods in Inje University

arduino-nodejs-plotly-streaming

This repo introduces a simple and efficient way to plot the streaming data from Arduino with Easy Pulse ppg sensor or DHT11 sensor.

HTML

hw-coding

Resource for lecture of Hardware Programming (2017, Inje university)

Arduino

Redwoods / Lec

 Unwatch ▾ 1

 Code

 Issues 0

 Pull requests 0

 Projects 0

 Wiki

 Insights

 Settings

All lectures by Redwoods in Inje University

Add topics

 81 commits

 1 branch

 0 releases

Branch: master ▾

New pull request

Create new file

Upload files

 Redwoods 2018 wk01 upload

Last

 advanced-Arduino-iot

wk16 exam upload

 ev3

wk16 final exam. answers

 healthcare-signal-iot

2018 wk01 upload

 html5-basic

2018 wk01 upload

 html5-mobile-simulation

wk15 lec upload

 Lec.Rproj

2018 wk01 upload

 README.md

wk03 upload and fix links

This repository Search Pull requests Issues Marketplace Explore

Unwatch 1

Code Issues 0 Pull requests 0 Projects 0 Wiki Insights Settings

Branch: master Lec / healthcare-signal-iot / Create new file Upload

Redwoods 2018 wk03 upload Latest

..

src	2018 wk03 upload
README.md	2018 wk01 upload
wk01_hs_Intro.pdf	2018 wk01 upload-2
wk01_hs_Intro.pptx	2018 wk01 upload-2
wk02_hs_nodejs.pdf	2018 wk02 upload
wk03_hs_node_express.pdf	2018 wk03 upload

README.md

Lec : Introduction to Healthcare Signal Visualization

All lectures by Redwoods in Inje University from 2018 and 2017.



1.0 What is node.js?

← → ⌂ ⌂ 🔒 안전함 | https://www.w3schools.com/nodejs/nodejs_intro.asp

HOME CSS JAVASCRIPT SQL PHP BOOTSTRAP HOW TO JQUERY MORE ▾

Node.js Tutorial
Node.js HOME
Node.js Intro
Node.js Get Started
Node.js Modules
Node.js HTTP Module
Node.js File System
Node.js URL Module
Node.js NPM
Node.js Events
Node.js Upload Files
Node.js Email

Node.js MySQL
MySQL Get Started
MySQL Create Database
MySQL Create Table

Node.js Introduction

< Previous

What is Node.js?

- Node.js is an open source server framework
- Node.js is free
- Node.js runs on various platforms (Windows, Linux, Unix, Mac OS X, etc.)
- Node.js uses JavaScript on the server

Why Node.js?

Node.js uses asynchronous programming!


https://www.w3schools.com/nodejs/nodejs_intro.asp

Target of this class


Real-time Weather Station from sensors



on Time: 2018-01-22 17:58:31.012



Project of this class





주교재

아두이노와 Node.js에 기반한

IOT 신호 시각화

| 저자 이상훈 |

인제대학교 출판부

아두이노와 Node.js에 기반한 IOT 신호 시각화

| 저자 이상훈 |



인제대학교 출판부